

HurryCane® Accessory Feet

HCPCS:



While every part of our HurryCane® products are built to last, you will need to occasionally replace the rubber feet as they will eventually wear down with normal use. A replacement set of feet are a smart investment so you're never unprepared. Each set of replacement feet contains three (3) feet and simple instructions on how to install them on your HurryCane® Freedom Edition. We recommend you change the base feet on your cane about once every six months with normal use. Note: For use only with the new HurryCane® Freedom Edition with cross-hatched tips. Not compatible with previous editions with rounded tips.

- Large cross-hatched tips give you even greater traction and help the HurryCane® Freedom Edition stand on its own even on carpet!
- For use only with the new HurryCane® Freedom Edition. Not compatible with previous editions with rounded tips.

PRODUCTS

Description

HCFEET-BK

HurryCane Replacement Feet, Retail