



		12R Serial #	15J Serial #	21S Serial #
1.	Knee Pad Screws (4ea)	95012R79601	95012R79601	95012R79601
2.	Brake Cable	95012R79602	95012R79602	95012R79602
3.	Wheel Lock w/o Pad Left	95012R79603	95021S79603	95021S79603
	Wheel Lock w/o Pad Right	95012R79604	95021S79604	95021S79604
4.	Wheel Lock Bolts (pr)	95012R79627	95012R79627	95012R79627
5.	Wheel Lock Spring	95012R79605	95012R79605	95012R79605
6.	Brake connecting Bar	95012R79606	95012R79606	95012R79606
7.	Brake Pad & Hardware	95012R79615	95012R79615	95012R79615
8.	Front or Rear Axle	95012R79608	95012R79608	95012R79608
9.	Front or Rear Wheel Assembly	95012R79609	95012R79609	95012R79609
10.	Hand Brake & Cable	95012R79610	95012R79610	95012R79610
11.	Knee Pad Post	95021S79611	95021S79611	95021S79611
12.	Knee Pad & Hardware (ea)	95012R79612	95012R79612	95012R79612
13.	Seat Post Release Lever	95012R79613	Not Used	95012R79613
14.	Knee Pad Adjustment Pin	95012R79614	Not Used	95012R79614
	Knee Pad Adjustment Knob	Not Used	95015J79628	Not Used
15.	Tiller Adjustment Knob	95012R79607	95012R79607	95012R79607
16.	Fork Stem Bearing Set	95012R79616	95012R79616	95012R79616
17.	Hand Grip (ea)	95012R79617	95021S79617	95021S79617
18.	Cable Retaining Ring	95012R79618	95012R79618	95012R79618
		12R Serial #	15J Serial #	21S Serial #
19.	Steering Handle Folding Hinge	95012R79619	95021S79627	95021S79627
20.	Steering Column Tension Spring	95012R79620	95012R79620	95012R79620
21.	Handlebar	95012R79621	95012R79621	95012R79621
22.	Steering Fork	95012R79622	95021S79622	95021S79622
23.	Handlebar Basket Mount	95012R79623	95021S79623	95021S79623
24.	Folding Release Lever	95012R79624	95012R79624	95012R79624
25.	Axle Retaining Bolts (4 ea)	95012R79625	95012R79625	95012R79625
26.	Basket	NLA	95021S79626	95021S79626
27.	Wheel Bearing (ea)	9503H79021	9503H79021	9503H79021