



- |  |  |
|--|--|
| <p>1. Handgrip- STDS2K3003</p> <p>2. Back Upholstery 20"- [2]<br/>Back Upholstery 22"- STDS2KBTR22B</p> <p>3. Seat upholstery 20"- STDS2KBTR20S<br/>Seat Upholstery 22"- STDS2KBTR22S</p> <p>4. Back Uphol. Hdwr (8 ea)- STDS5D5504</p> <p>5. Arm Pad- STDSDSKVB</p> <p>6. Arm Assembly Blue Left- STDS4S30LB [1]<br/>Arm Assy Blue Right- STDS4S30RB [1]<br/>Arm Assembly Red Left- STDS4S30LR [1]<br/>Arm Assy Red Right- STDS4S30RR [1]</p> <p>7. Wheel Lock Left- STDS2K303L<br/>Wheel Lock Right- STDS2K303R<br/>Wheel Lock Tip- STDS8M4603</p> <p>8. Tipping Sleeve- STDS2K3015</p> <p>9. Rear Wheel Bearing- STDS2K3031</p> <p>10. Hub Cap- STDS2K3002</p> <p>11. Rear Axle- STDS2K3032 [3]</p> <p>12. Rear Wheel- STDS2K3000</p> | <p>13. Cross Frame 20"- [2]<br/>Cross Frame 22"- [2]</p> <p>14. Hanger Pins (4 ea)- STDS1069-4</p> <p>15. Caster Axle- STDS2K3042</p> <p>16. Caster Bearing- STDS1011</p> <p>17. Caster- STDS2K3009</p> <p>18. Fork (4S s/n)- STDS4S3006F [3]</p> <p>19. Fork Bearing Flange - STDS3J2401<br/>Fork Bearing Non-Flange- STDS8M4601</p> <p>20. Dust Cap- STDS8M4651</p> <p>21. Slide Tube- STDS2K3010</p> <p>22. Release Button- STDS3J4503</p> <p>23. Footrest Bumper- STDS1026</p> <p>24. Footrest (pr) Blue- STDS2K305B<br/>Footrest (pr) Red- STDS2K305R</p> <p>25. Release Lever Left- [2]<br/>Release Lever Right- STDS3J091R [3]</p> <p>26. Seat Uphol. Hardware (8 ea)- STDS1072-8</p> <p>27. Upholstery Strap- STDS2K3012 [3]</p> |
|--|--|

[1] 4S2011... and later.  
 [2] Part is no longer available.  
 [3] When stock is gone the part will be no longer available.