



- | | |
|---|---|
| <ul style="list-style-type: none"> 1. Handgrip- STDS29SK5-02 2. Back Cane- STDS29SK5-01 3. Back Ht Adj Knob (pr)- STDS29SK5-23 4. 16" Back Upholstery - STDS29SK5-03 18" Back Upholstery- STDS29SK5-04 20" Back Upholstery- STDS29SK5-05 5. Desk Arm Pad- STDS29SK5-06 6. Ht Adj Arm Left- STDS29SK5-09 Ht Adj Arm Right- STDS29SK5-08 7. Upper Armrest - STDS29SK5-42 8. Ht Adj Armrest Button- STDS29SK5-43 9. Rear Armrest Receiver- STDS29SK5-07 10. Armrest Saddle Right- STDS29SK5-37 Armrest Saddle Left- STDS29SK5-38 11. 16" Seat Upholstery - STDS29SK5-10 18" Seat Upholstery - STDS29SK5-11 20" Seat Upholstery - STDS29SK5-12 12. Seat Belt - STDS29SK5-21 13. Rear Seat Saddle- STDS29SK5-36 14. Fork- STDS29SK5-16 15. Dust Cap- STDS29SK5-32 16. Fork Stem Bearing (pr)- STDS29SK5-14 17. Caster- STDS29SK5-17 18. Caster Axle- STDS29SK5-15 19. Caster Bearing- STDS1011 20. Rear Wheel & Hand Rim- STDS29SK5-18 | <ul style="list-style-type: none"> 21. Hand Rim & Hardware- STDS29SK5-25 22. Quick Release Axle - STDS29SK5-19 23. Axle Receiver Assy- STDS29SK5-20 24. Rear Wheel Bearing- STDS1060 25. Footrest - STDS29SK5-13 26. Footrest Bumper- STDS29SK5-26 27. Heel Loop (pr)- STDS29SK5-24 28. 16" Cross Frame- STDS29SK5-27 [1] 16" Cross Frame- STDS29SK5-27SE [2] 18" Cross Frame- STDS29SK5-28 [1] 18" Cross Frame- STDS29SK5-28SE [2] 20" Cross Frame- STDS29SK5-29 [1] 20" Cross Frame- STDS29SK5-29SE [2] Cross Frame Extension- STDS29SK5-44 29. 16" Cross Frame Assist- STDS29SK5-33 18" Cross Frame Assist- STDS29SK5-34 20" Cross Frame Assist- STDS29SK5-35 30. Side Frame, Right - STDS29SK5-30 Side Frame, Left, - STDS29SK5-31 31. Left Brake- STDS29SK5-39 Right Brake- STDS29SK5-40 32. Brake Tip- STDS29SK5-41 Brake Extension (ea)- STDS801GT 33. Anti-Tippers (pr)- STDS29SK5-22 Not Shown- ELR (pr)- STDS29SK5-ELR |
|---|---|

[1] Comes without seat extensions.

[2] Comes seat extensions.