



Serial Number	3J	4S	5D
1.	Handgrip	STDS3J2403	STDS3J2403
2.	Rear Wheel	STDS3J2424	STDS3J2424
3.	Hand Rim	STDS3J2400	STDS3J2400
4.	Hand Rim Screws (9 ea)	STDS004609-9	STDS004609-9
5.	Rear Seat Saddle	STDS3J2414	STDS3J2414
6.	Rear Wheel Bearing	STDS3J2413	STDS3J2413
7.	Rear Axle	STDS3J2425	STDS3J2425
8.	Hub Cap	STDS3J2421	STDS3J2421
9.	Push to Wheel Lock Brake Lt	STDS4S221L	STDS4S221L
	Push to Lock Wheel Lock Rt	STDS4S221R	STDS4S221R
	Pull to Lock Wheel Lock Lt	STDSK234-PTL	STDSK234-PTL
	Pull to Lock Wheel Lock Rt	STDSK234-PTR	STDSK234-PTR
	Wheel Lock Tip	STDS8M4603	STDS8M4603
10.	Front Seat Saddle	STDS3J2412	STDS3J2412
11.	Axle Cap	STDS001000	STDS001000
12.	Bumper	STDS3J2450	STDS3J2450
13.	Heel Loop & Peg	STDS831	STDS831
	Heel loop Peg	STDS3J24SF-HP	STDS3J24SF-HP
14.	Hanger Pins (4 ea)	Not Used	STDS5D1069
15.	Caster 8 Spoke	STDS3J2432	STDS4S2432
	Caster 5 Spoke	STDS3J3900	Not Applicable
16.	Caster Axle	STDS3J2431	STDS8M4631
17.	Caster Bearing	STDS1011	STDS4S3602
18.	Fork	STDS3J2433	STDS8M4633
19.	Fork Stem Bearing	STDS3J2401	STDS8M4601
20.	Dust Cap	STDS8M4651	STDS8M4651
21.	Side Frame Left	[2]	STDS5D24L1
	Side Frame Right	[2]	STDS5D24R1
Serial Number	3J	4S	5D
22.	Cross Frame 16"	STDS3J24X6-AD [4]	Not Applicable
	Cross Frame 18"	STDS3J24X8-AD [4]	Not Applicable
	Cross Frame 20"	STDS3J242X-AD [4]	Not Applicable
	Cross Frame 16" Adj. Depth	Not Used	STDS3J24X6-AD
	Cross Frame 18" Adj. Depth	Not Used	STDS3J24X8-AD
	Cross Frame 20" Adj. Depth	Not Used	STDS3J242X-AD
23.	Seat Upholstery 16"	STDS3J2416	Not Applicable
	Seat Upholstery 18"	STDS3J2418	Not Applicable
	Seat Upholstery 20"	STDS3J2420	Not Applicable
	Seat Uphl. 16" Adj. Depth	Not Applicable	STDS4S2416-AD
	Seat Uphl. 18" Adj. Depth	Not Applicable	STDS4S2418-AD
	Seat Uphl. 20" Adj. Depth	Not Applicable	STDS4S2420-AD
24.	Release Lever	STDS3J2419	STDS3J2419
25.	Arm Assy. Full Left	STDS3J24LF	STDS3J24LF
	Arm Assy. Full Right	STDS3J24RF	STDS3J24RF
	Arm Assy. Desk Left	STDS3J24DL	STDS3J24DL
	Arm Assy. Desk Right	STDS3J24DR	STDS3J24DR
	Adj. Ht Arm Assy. Full Left	STDS3J24AFL	STDS3J24AFL
	Adj. Ht Arm Assy. Full Right	STDS3J24AFR	STDS3J24AFR
	Adj. Ht Arm Assy. Desk Left	STDS3J24AL	STDS3J24AL
	Adj. Ht Arm Assy. Desk Rt	STDS3J24AR	STDS3J24AR
25a.	Upper Adj. Arm Full Left	STDS3J24AFL-UFL [3]	STDS3J24AFL-UFL [3]
	Upper Adj. Arm Full Right	STDS3J24AFR-UFR [3]	STDS3J24AFR-UFR [3]
	Upper Adj. Arm Desk Left	STDS3J24AL-UDL [3]	STDS3J24AL-UDL [3]
	Upper Adj. Arm Desk Right	STDS3J24AR-UDR [3]	STDS3J24AR-UDR [3]
26.	Adj. Height Release Left	STDS2A0046	STDS2A0046
	Adj. Height Release Right	STDS2A0044	STDS2A0044
Serial Number	3J	4S	5D
27.	Arm Pad Desk	STDSDSKVB	STDSDSKVB
	Arm Pad Full	STDSFLVB	STDSFLVB
28.	Back Upholstery 16"	STDS3J2406 [1]	STDS3J2406 [1]
	Back Upholstery 18"	STDS3J2408	STDS3J2408
	Back Upholstery 20"	STDS3J2402	STDS3J2402
	Back Uphol. 16" Adj. Depth	Not Applicable	STDS4S2406N
	Back Uphol. 18" Adj. Depth	Not Applicable	STDS4S2408N
	Back Uphol. 20" Adj. Depth	Not Applicable	STDS4S2402N
29.	Flip Back Arm Bracket	STDS3J2409	STDS3J2409
30.	Upholstery Strap	STDS3J2411	STDS3J2411
31.	Tipping Sleeve	STDS3J2422	STDS3J2422
32.	Cross Frame Assist 16"	STDS3J2436	STDS3J2436
	Cross Frame Assist 18"	STDS3J2438	STDS3J2438
	Cross Frame Assist 20"	STDS3J2440	STDS3J2440
33.	Rear Arm Bracket	Not Applicable	STDS5D2499
34.	Seat Extension Screw (pr)	Not Applicable	STDS5D24XF-S
	Seat Extension & Screw (pr)	Not Applicable	STDS5D24XF-ET
35.	Cross Frame Bolt	STDS001061-K3	STDS001061-K3
36.	Footplate & Heelloop Left	STDS3J2410L	STDS3J2410L
	Footplate & Heelloop Right	STDS3J2410R	STDS3J2410R
37.	Footrest (pr)	STDS3J24SF	STDS3J24SF
	Elevating Leg Lest (pr)	LK3JELR	LK3JELR

[1] When stock is gone the part is no longer available.

[2] Stock is gone the part is no longer available.

[3] Includes arm pad.

[4] This is a substitute for original part.