



Serial Number	Y	1S &4S	2A	Silver Vein
1.	Back Uphol 20"	STDS2329BLK	STDS2329BLK	STDS2329BLK
	Back Uphol 22"	STDS2331BLK	STDS2331BLK	STDS2331BLK
	Back Uphol 24"	STDS2333BLK	STDS2333BLK	STDS2333BLK
2.	Handgrip	STDS871	STDS871	STDS871
3.	Back Uphol Hardware (8 ea)	STDS5D5504	STDS5D5504	STDS5D5504
4.	Rear Wheel Chrome Handrim	STDS1000HD	STDS1S1000HD	Not Applicable
	Rear Wheel Black Handrim	Not Applicable	STDS1S1000HD-SV	STDS1S1000HD-SV
5.	Hub Cap	STDS1000C	STDS1055	STDS1000C
6.	Rear Axle Bolt	STDS1052	STDS1S1053	STDS1052
7.	Rear Axle Bearing	STDS1012HD	STDS1S1012	STDS1012HD
8.	Hand Rim	STDS005008	STDS004010	STDS005008
9.	Side Frame Left	[1]	STDS4S521L	[1]
	Side Frame Right	[1]	STDS4S521R	[1]
10.	Hand Rim Hardware (8 ea)	STDS1016-8	STDS1016-8	STDS1016-8
11.	Cross Frame 20"	[1]	[1]	[1]
	Cross Frame 22" 6 Screw holes	STDS2A5222	STDS2A5222	STDS2A5222
	Cross Frame 24"	[1]	[1]	[1]
12.	Cross Frame Bolt	[1]	[1]	[1]
13.	Wheel Lock Tip	STDS8M4603	STDS8M4603	STDS4011
14.	Wheel Lock Left	STDS4010L	STDS4010L	STDS4010L
	Wheel Lock Right	STDS4010R	STDS4010R	STDS4010R
15.	Front Axle Bolt	STDS1014	STDS1014	STDS1014
Serial Number	Y	1S &4S	2A	Silver Vein
16.	Caster Bearings	STDS1011	STDS1011	STDS1011
17.	Caster	STDS1075	STDS1075	STDS1075
	Caster for Hemi Height	STDS1074	STDS1074	STDS1074
18.	Caster Fork	STDS3045-2	STDS3045-2	STDS3045-2
19.	Fork Stem Bearing	STDS1060	STDS1060	STDS1060
20.	Fork Stem Dust Cap	STDS1051	STDS1051	STDS1051
21.	Seat Uphol 5 Screw Holes 20"	Not Applicable	Not Applicable	STDS2328BLK
	Seat Uphol 5 Screw Holes 22"	Not Applicable	Not Applicable	STDS2330BLK
	Seat Uphol 5 Screw Holes 24"	Not Applicable	Not Applicable	STDS2332BLK
	Seat Uphol 6 Screw Holes 20"	STDS2A2328BLK	STDS2A2328BLK	STDS2A2328BLK
	Seat Uphol 6 Screw Holes 22"	STDS2A2330BLK	STDS2A2330BLK	STDS2A2330BLK
	Seat Uphol 6 Screw Holes 24"	STDS2A2332BLK	STDS2A2332BLK	STDS2A2332BLK
22.	Seat Uphol Hardware (8 ea)	STDS1072-8	STDS1072-8	STDS1072-8
23.	Arm Assembly Desk Left	STDSDDASL	STDSDDASL	STDSDDASL
	Arm Assembly Desk Right	STDSDDASR	STDSDDASR	STDSDDASR
	Arm Assembly Full Left	STDSDFASL	STDSDFASL	STDSDFASL
	Arm Assembly Full Right	STDSDFASR	STDSDFASR	STDSDFASR
	Arm Assembly Adj. Desk Lt	STDSADDASPL	STDSADDASPL	STDSADDASPL
	Arm Assembly Adj. Desk Rt	STDSADDASPR	STDSADDASPR	STDSADDASPR
	Arm Assembly Adj. Full Lt	STDSADFASPL	STDSADFASPL	STDSADFASPL
	Arm Assembly Adj. Full Rt	STDSADFASPR	STDSADFASPR	STDSADFASPR
Serial Number	Y	1S &4S	2A	Silver Vein
24.	Arm Pad Desk	STDSDSKVB	STDSDSKVB	STDSDSKVB
	Arm Pad Full	STDSFLVB	STDSFLVB	STDSFLVB
	Arm Pad Bolt	STDS002001	STDS002001	STDS002001
25.	Arm Rest Panel Desk	STDS002044	STDS002044	STDS002044
	Arm Rest Panel Full	STDS002043	STDS002043	STDS002043
26.	Arm Release Button	STDSSB	STDSSB	STDSSB
27.	Slide Tube	STDS005200	STDS005200	STDS005200
28.	Footrest	STDSF-TF	STDSF-TF	STDSF-TF
	Elevating Leg Rest	STDELR-TF	STDELR-TF	STDELR-TF
	Release Lever Left	Not Applicable	Not Applicable	STDS00004L [2]
	Release Lever Right	Not Applicable	Not Applicable	STDS00004R [2]
	Footrest Adjustment Bolt	Not Applicable	Not Applicable	STDS001051
29.	Footplate	[1]	[1]	[1]
30.	Rubber Bumper	STDS1026	STDS1026	STDS1026
31.	Tipping Sleeve	STDS4020	STDS4020	STDS4020
32.	Seat Rail Guide	STDS1070	STDS1070	STDS1070

[1] Part is no longer available.

[2] For original Footrest and ELR, not STDSSF-TF or STDSELR-TF